

AW-XB547NF

**IEEE 802.11a/b/g/n/ac/ax Wireless LAN
with Bluetooth 5.2 LGA Module**

Wi-Fi(PCIe)+Bluetooth(USB)

Linux OS

RF Test Commands User Guide

Rev. 0.2

(For Standard)

Revision History

Version	Revision Date	Description	Initials	Approved
0.1	2022/08/25	● Initial Version	Wiley.Zhu	
0.2	2023/03/15	● Update BLE Continue Tx command	Wiley.Zhu	

Inspired by wireless

Confidential

• Warning!! This is a message from Azurewave and the information you are viewing now is strictly confidential and is a knowledge property to Azurewave.
• Unauthorized use of this document is prohibited and Azurewave retains the right for legal actions against any loss suffered or expenditure due to the misuse of any information from this document.

Table of Contents

1. AW-XB547NF Antenna ports configuration.....	3
2. Wi-Fi RF test commands.....	3
2.1. Main Port 2.4GHz Wi-Fi packet Tx commands	5
2.2. Aux Port 2.4GHz Wi-Fi packet Tx commands.....	6
2.3. Main Ports 5GHz Wi-Fi packet Tx commands	7
2.4. Aux Port 5GHz Wi-Fi packet Tx Commands	9
2.5. Main+Aux Port 2.4GHz Wi-Fi packet Tx Commands.....	11
2.6. Main+Aux Ports 5GHz Wi-Fi packet Tx Commands.....	12
2.7. Main Port Wi-Fi single tone/CW Tx commands.....	13
2.8. Aux Port Wi-Fi single tone/CW Tx commands	14
2.9. Main Port Wi-Fi Rx sensitivity commands	14
2.10. Aux Port Wi-Fi Rx sensitivity commands.....	15
2.11. Main+Aux Ports WiFi Rx sensitivity commands	16
3. Bluetooth RF test commands.....	17
3.1. Bluetooth classic/EDR test mode commands.....	18
3.2. Bluetooth classic/EDR packet Tx commands	18
3.3. Bluetooth classic/EDR continuous Tx commands	18
3.4. Bluetooth BLE 1Mbps packet Tx commands	19
3.5. Bluetooth BLE 2Mbps packet Tx commands	19
3.6. Bluetooth BLE 1Mbps continuous Tx commands.....	20
3.7. Bluetooth BLE 2Mbps continuous Tx commands.....	20
3.8. Bluetooth classic/EDR hopping mode Tx commands	21
3.9. Bluetooth BLE hopping mode Tx commands	21
3.10. Bluetooth/BLE single tone/CW Tx commands	21
3.11. Bluetooth classic/EDR packet Rx sensitivity commands.....	22
3.12. Bluetooth BLE Packet Rx sensitivity commands	22

1. AW-XB547NF Antenna ports configuration

Antenna	I-PEX MHF4 Connector Receptacle (20449) ANT1(AUX) : WiFi/Bluetooth → TX/RX ANT2(Main) : WiFi → TX/RX
----------------	--



2. Wi-Fi RF test commands

Test environment settings:

请把 Wi-Fi 测试工具 rtwpriv 复制到机器，并修改 rtwpriv 的运行权限。

```
cp rtwpriv /usr/sbin/rtwpriv  
chmod 755 /usr/sbin/rtwpriv
```

Wi-Fi Tx commands introduce:

```
rtwpriv wlp5s0 mp_start
```

```
//Start mp mode
rtwpriv wlp5s0 1 0 a 11M 1 2000
//第一位设置信道，1 代表信道 1；
//第二位设置带宽，0 代表 20M 带宽，1 代表 40M 带宽，2 代表 80M 带宽；
//第三位设置天线，a 代表天线 Main，b 代表天线 Aux，ab 代表 2x2 天线 Main 和
Aux；
//第四位设置速率，11M 代表 802.11b 模式的 11M 速率（1M--11M），
54M 代表 802.11g 模式的 54M 速率（6M--54M），
HTMCS7 代表 802.11n 1x1 模式的 MCS 速率（HTMCS0--HTMCS7），
HTMCS15 代表 802.11n 2x2 模式的 MCS 速率（HTMCS8--HTMCS15），
VHT1MCS9 代表 802.11ac 模式的 MCS 速率（VHT1MCS0--
VHT1MCS9），
HE1MCS11 代表 802.11ax 模式的 MCS 速率（HE1MCS0--HE1MCS11）；
//第五位设置发射模式，1 代表 Packet Tx，2 代表 Continuous Tx，3 代表 Single
Tone。
rtwpriv wlp5s0 mp_txpower dbm=19
//设置发射功率，dbm=19 代表 19dBm
rtwpriv wlp5s0 stop
//停止发射
```

Wi-Fi Rx commands introduce:

```
rtwpriv wlp5s0 mp_start
//Start mp mode
rtwpriv wlp5s0 mp_channel 36
//设置信道，36 代表信道 36
rtwpriv wlp5s0 mp_ant_rx a
//设置天线，a 代表天线 Main，b 代表天线 Aux，ab 代表 2x2 天线 Main 和 Aux
rtwpriv wlp5s0 mp_bandwidth 40M=0,shortGI=0
//设置带宽，40M=0 代表 20MHz 带宽，40M=1 代表 40MHz 带宽，40M=2 代表
80MHz 带宽
rtwpriv wlp5s0 mp_arx start
//开始 Rx 接收测试
rtwpriv wlp5s0 mp_reset_stats
//复位 Rx 接收包计数器
*****测试仪器发送 Wi-Fi 数据包*****
rtwpriv wlp5s0 mp_arx phy
```

```
//统计 Rx 接收数据包  
rtwpriv wlp5s0 mp_stop  
//停止测试
```

2.1. Main Port 2.4GHz Wi-Fi packet Tx commands

1. Main Port Wi-Fi Tx on **Channel 1** at **19dBm** with an 802.11b **11Mbps data rate** in 2.4GHz 20MHz BW mode

```
rtwpriv wlp5s0 mp_start  
rtwpriv wlp5s0 1 0 a 11M 1 2000  
rtwpriv wlp5s0 mp_txpower dbm=19  
rtwpriv wlp5s0 stop
```

-
2. Main Port Wi-Fi Tx on **Channel 1** at **18dBm** with an 802.11g **54Mbps data rate** in 2.4GHz 20MHz BW mode

```
rtwpriv wlp5s0 mp_start  
rtwpriv wlp5s0 1 0 a 54M 1 2000  
rtwpriv wlp5s0 mp_txpower dbm=18  
rtwpriv wlp5s0 stop
```

-
3. Main Port Wi-Fi Tx on **Channel 1** at **17dBm** with an 802.11n **MCS7 data rate** in 2.4GHz 20MHz BW mode

```
rtwpriv wlp5s0 mp_start  
rtwpriv wlp5s0 1 0 a HTMCS7 1 2000  
rtwpriv wlp5s0 mp_txpower dbm=17  
rtwpriv wlp5s0 stop
```

-
4. Main Port Wi-Fi Tx on **Channel 3** at **17dBm** with an 802.11n **MCS7 data rate** in 2.4GHz 40MHz BW mode

```
rtwpriv wlp5s0 mp_start  
rtwpriv wlp5s0 3 1 a HTMCS7 1 2000  
rtwpriv wlp5s0 mp_txpower dbm=17  
rtwpriv wlp5s0 stop
```

-
5. Main Port Wi-Fi Tx on **Channel 1** at **13dBm** with an 802.11ax **MCS11 data rate** in 2.4GHz 20MHz BW mode

```
rtwpriv wlp5s0 mp_start  
rtwpriv wlp5s0 1 0 a HE1MCS11 1 2000  
rtwpriv wlp5s0 mp_txpower dbm=13  
rtwpriv wlp5s0 stop
```

-
6. Main Port Wi-Fi Tx on **Channel 3** at **13dBm** with an 802.11ax **MCS11 data rate** in 2.4GHz 40MHz BW mode

```
rtwpriv wlp5s0 mp_start  
rtwpriv wlp5s0 3 1 a HE1MCS11 1 2000  
rtwpriv wlp5s0 mp_txpower dbm=13  
rtwpriv wlp5s0 stop
```

2.2. Aux Port 2.4GHz Wi-Fi packet Tx commands

1. Aux Port Wi-Fi Tx on **Channel 1** at **19dBm** with an 802.11b **11Mbps data rate** in 2.4GHz 20MHz BW mode

```
rtwpriv wlp5s0 mp_start  
rtwpriv wlp5s0 1 0 b 11M 1 2000  
rtwpriv wlp5s0 mp_txpower dbm=19  
rtwpriv wlp5s0 stop
```

-
2. Aux Port Wi-Fi Tx on **Channel 1** at **18dBm** with an 802.11g **54Mbps data rate** in 2.4GHz 20MHz BW mode

```
rtwpriv wlp5s0 mp_start  
rtwpriv wlp5s0 1 0 b 54M 1 2000  
rtwpriv wlp5s0 mp_txpower dbm=18  
rtwpriv wlp5s0 stop
```

-
3. Aux Port Wi-Fi Tx on **Channel 1** at **17dBm** with an 802.11n **MCS7 data rate** in 2.4GHz 20MHz BW mode

```
rtwpriv wlp5s0 mp_start  
rtwpriv wlp5s0 1 0 b HTMCS7 1 2000  
rtwpriv wlp5s0 mp_txpower dbm=17  
rtwpriv wlp5s0 stop
```

-
- Aux Port Wi-Fi Tx on **Channel 3** at **17dBm** with an 802.11n **MCS7 data rate** in 2.4GHz 40MHz BW mode

```
rtwpriv wlp5s0 mp_start
rtwpriv wlp5s0 3 1 b HTMCS7 1 2000
rtwpriv wlp5s0 mp_txpower dbm=17
rtwpriv wlp5s0 stop
```

-
- Aux Port Wi-Fi Tx on **Channel 1** at **13dBm** with an 802.11ax **MCS11 data rate** in 2.4GHz 20MHz BW mode

```
rtwpriv wlp5s0 mp_start
rtwpriv wlp5s0 1 0 b HE1MCS11 1 2000
rtwpriv wlp5s0 mp_txpower dbm=13
rtwpriv wlp5s0 stop
```

-
- Aux Port Wi-Fi Tx on **Channel 3** at **13dBm** with an 802.11ax **MCS11 data rate** in 2.4GHz 40MHz BW mode

```
rtwpriv wlp5s0 mp_start
rtwpriv wlp5s0 3 1 b HE1MCS11 1 2000
rtwpriv wlp5s0 mp_txpower dbm=13
rtwpriv wlp5s0 stop
```

2.3. Main Ports 5GHz Wi-Fi packet Tx commands

- Main Port Wi-Fi Tx on **Channel 36** at **18dBm** with an 802.11a **54Mbps data rate** in 5GHz 20MHz BW mode

```
rtwpriv wlp5s0 mp_start
rtwpriv wlp5s0 36 0 a 54M 1 2000
rtwpriv wlp5s0 mp_txpower dbm=18
rtwpriv wlp5s0 stop
```

-
- Main Port Wi-Fi Tx on **Channel 36** at **17dBm** with an 802.11n **MCS7 data rate** in 5GHz 20MHz BW mode

```
rtwpriv wlp5s0 mp_start
rtwpriv wlp5s0 36 0 a HTMCS7 1 2000
```

```
rtwpriv wlp5s0 mp_txpower dbm=17  
rtwpriv wlp5s0 stop
```

-
3. Main Port Wi-Fi Tx on **Channel 38** at **17dBm** with an 802.11n **MCS7 data rate** in 5GHz 40MHz BW mode

```
rtwpriv wlp5s0 mp_start  
rtwpriv wlp5s0 38 1 a HTMCS7 1 2000  
rtwpriv wlp5s0 mp_txpower dbm=17  
rtwpriv wlp5s0 stop
```

-
4. Main Port Wi-Fi Tx on **Channel 36** at **16dBm** with an 802.11ac **MCS8 data rate** in 5GHz 20MHz BW mode

```
rtwpriv wlp5s0 mp_start  
rtwpriv wlp5s0 36 0 a VHT1MCS8 1 2000  
rtwpriv wlp5s0 mp_txpower dbm=16  
rtwpriv wlp5s0 stop
```

-
5. Main Port Wi-Fi Tx on **Channel 38** at **15dBm** with an 802.11ac **MCS9 data rate** in 5GHz 40MHz BW mode

```
rtwpriv wlp5s0 mp_start  
rtwpriv wlp5s0 38 1 a VHT1MCS9 1 2000  
rtwpriv wlp5s0 mp_txpower dbm=15  
rtwpriv wlp5s0 stop
```

-
6. Main Port Wi-Fi Tx on **Channel 42** at **15dBm** with an 802.11ac **MCS9 data rate** in 5GHz 80MHz BW mode

```
rtwpriv wlp5s0 mp_start  
rtwpriv wlp5s0 42 2 a VHT1MCS9 1 2000  
rtwpriv wlp5s0 mp_txpower dbm=15  
rtwpriv wlp5s0 stop
```

-
7. Main Port Wi-Fi Tx on **Channel 36** at **13dBm** with an 802.11ax **MCS11 data rate** in 5GHz 20MHz BW mode

```
rtwpriv wlp5s0 mp_start  
rtwpriv wlp5s0 36 0 a HE1MCS11 1 2000  
rtwpriv wlp5s0 mp_txpower dbm=13  
rtwpriv wlp5s0 stop
```


-
8. Main Port Wi-Fi Tx on **Channel 38** at **13dBm** with an 802.11ax **MCS11 data rate** in 5GHz 40MHz BW mode

```
rtwpriv wlp5s0 mp_start  
rtwpriv wlp5s0 38 1 a HE1MCS11 1 2000  
rtwpriv wlp5s0 mp_txpower dbm=13  
rtwpriv wlp5s0 stop
```

-
9. Main Port Wi-Fi Tx on **Channel 42** at **13dBm** with an 802.11ax **MCS11 data rate** in 5GHz 80MHz BW mode

```
rtwpriv wlp5s0 mp_start  
rtwpriv wlp5s0 42 2 a HE1MCS11 1 2000  
rtwpriv wlp5s0 mp_txpower dbm=13  
rtwpriv wlp5s0 stop
```

2.4. Aux Port 5GHz Wi-Fi packet Tx Commands

1. Aux Port Wi-Fi Tx on **Channel 36** at **18dBm** with an 802.11a **54Mbps data rate** in 5GHz 20MHz BW mode

```
rtwpriv wlp5s0 mp_start  
rtwpriv wlp5s0 36 0 b 54M 1 2000  
rtwpriv wlp5s0 mp_txpower dbm=18  
rtwpriv wlp5s0 stop
```

-
2. Aux Port Wi-Fi Tx on **Channel 36** at **17dBm** with an 802.11n **MCS7 data rate** in 5GHz 20MHz BW mode

```
rtwpriv wlp5s0 mp_start  
rtwpriv wlp5s0 36 0 b HTMCS7 1 2000  
rtwpriv wlp5s0 mp_txpower dbm=17  
rtwpriv wlp5s0 stop
```

-
3. Aux Port Wi-Fi Tx on **Channel 38** at **17dBm** with an 802.11n **MCS7 data rate** in 5GHz 40MHz BW mode

```
rtwpriv wlp5s0 mp_start
```

```
rtwpriv wlp5s0 38 1 b HTMCS7 1 2000
rtwpriv wlp5s0 mp_txpower dbm=17
rtwpriv wlp5s0 stop
```

-
4. Aux Port Wi-Fi Tx on **Channel 36** at **16dBm** with an 802.11ac **MCS8 data rate** in 5GHz 20MHz BW mode

```
rtwpriv wlp5s0 mp_start
rtwpriv wlp5s0 36 0 b VHT1MCS8 1 2000
rtwpriv wlp5s0 mp_txpower dbm=16
rtwpriv wlp5s0 stop
```

-
5. Aux Port Wi-Fi Tx on **Channel 38** at **15dBm** with an 802.11ac **MCS9 data rate** in 5GHz 40MHz BW mode

```
rtwpriv wlp5s0 mp_start
rtwpriv wlp5s0 38 1 b VHT1MCS9 1 2000
rtwpriv wlp5s0 mp_txpower dbm=15
rtwpriv wlp5s0 stop
```

-
6. Aux Port Wi-Fi Tx on **Channel 42** at **15dBm** with an 802.11ac **MCS9 data rate** in 5GHz 80MHz BW mode

```
rtwpriv wlp5s0 mp_start
rtwpriv wlp5s0 42 2 b VHT1MCS9 1 2000
rtwpriv wlp5s0 mp_txpower dbm=15
rtwpriv wlp5s0 stop
```

-
7. Aux Port Wi-Fi Tx on **Channel 36** at **13dBm** with an 802.11ax **MCS11 data rate** in 5GHz 20MHz BW mode

```
rtwpriv wlp5s0 mp_start
rtwpriv wlp5s0 36 0 b HE1MCS11 1 2000
rtwpriv wlp5s0 mp_txpower dbm=13
rtwpriv wlp5s0 stop
```

-
8. Aux Port Wi-Fi Tx on **Channel 38** at **13dBm** with an 802.11ax **MCS11 data rate** in 5GHz 40MHz BW mode

```
rtwpriv wlp5s0 mp_start
rtwpriv wlp5s0 38 1 b HE1MCS11 1 2000
rtwpriv wlp5s0 mp_txpower dbm=13
```

```
rtwpriv wlp5s0 stop
```

-
9. Aux Port Wi-Fi Tx on **Channel 42** at **13dBm** with an 802.11ax **MCS11 data rate** in 5GHz 80MHz BW mode

```
rtwpriv wlp5s0 mp_start  
rtwpriv wlp5s0 42 2 b HE1MCS11 1 2000  
rtwpriv wlp5s0 mp_txpower dbm=13  
rtwpriv wlp5s0 stop
```

2.5. Main+Aux Port 2.4GHz Wi-Fi packet Tx Commands

-
1. Main+Aux Port Wi-Fi Tx on **Channel 1** at **17dBm** with an 802.11n **MCS15 data rate** in 2.4GHz 20MHz BW mode

```
rtwpriv wlp5s0 mp_start  
rtwpriv wlp5s0 1 0 ab HTMCS15 1 2000  
rtwpriv wlp5s0 mp_txpower dbm=17  
rtwpriv wlp5s0 stop
```

-
2. Main+Aux Port Wi-Fi Tx on **Channel 3** at **17dBm** with an 802.11n **MCS15 data rate** in 2.4GHz 40MHz BW mode

```
rtwpriv wlp5s0 mp_start  
rtwpriv wlp5s0 3 1 ab HTMCS15 1 2000  
rtwpriv wlp5s0 mp_txpower dbm=17  
rtwpriv wlp5s0 stop
```

-
3. Main+Aux Port Wi-Fi Tx on **Channel 1** at **13dBm** with an 802.11ax **MCS11 data rate** in 2.4GHz 20MHz BW mode

```
rtwpriv wlp5s0 mp_start  
rtwpriv wlp5s0 1 0 ab HE1MCS11 1 2000  
rtwpriv wlp5s0 mp_txpower dbm=13  
rtwpriv wlp5s0 stop
```

-
4. Main+Aux Port Wi-Fi Tx on **Channel 3** at **13dBm** with an 802.11ax **MCS11 data rate** in 2.4GHz 40MHz BW mode

```
rtwpriv wlp5s0 mp_start
```

```
rtwpriv wlp5s0 3 1 ab HE1MCS11 1 2000
rtwpriv wlp5s0 mp_txpower dbm=13
rtwpriv wlp5s0 stop
```

2.6. Main+Aux Ports 5GHz Wi-Fi packet Tx Commands

1. Main+Aux Port Wi-Fi Tx on **Channel 36** at **17dBm** with an 802.11n **MCS15 data rate** in 5GHz 20MHz BW mode

```
rtwpriv wlp5s0 mp_start
rtwpriv wlp5s0 36 0 ab HTMCS15 1 2000
rtwpriv wlp5s0 mp_txpower dbm=17
rtwpriv wlp5s0 stop
```

2. Main+Aux Port Wi-Fi Tx on **Channel 38** at **17dBm** with an 802.11n **MCS15 data rate** in 5GHz 40MHz BW mode

```
rtwpriv wlp5s0 mp_start
rtwpriv wlp5s0 38 1 ab HTMCS15 1 2000
rtwpriv wlp5s0 mp_txpower dbm=17
rtwpriv wlp5s0 stop
```

3. Main+Aux Port Wi-Fi Tx on **Channel 36** at **16dBm** with an 802.11ac **MCS8 data rate** in 5GHz 20MHz BW mode

```
rtwpriv wlp5s0 mp_start
rtwpriv wlp5s0 36 0 ab VHT1MCS8 1 2000
rtwpriv wlp5s0 mp_txpower dbm=16
rtwpriv wlp5s0 stop
```

4. Main+Aux Port Wi-Fi Tx on **Channel 38** at **15dBm** with an 802.11ac **MCS9 data rate** in 5GHz 40MHz BW mode

```
rtwpriv wlp5s0 mp_start
rtwpriv wlp5s0 38 1 ab VHT1MCS9 1 2000
rtwpriv wlp5s0 mp_txpower dbm=15
rtwpriv wlp5s0 stop
```

5. Main+Aux Port Wi-Fi Tx on **Channel 42** at **15dBm** with an 802.11ac **MCS9 data rate** in

5GHz 80MHz BW mode

```
rtwpriv wlp5s0 mp_start  
rtwpriv wlp5s0 42 2 ab VHT1MCS9 1 2000  
rtwpriv wlp5s0 mp_txpower dbm=15  
rtwpriv wlp5s0 stop
```

-
6. Main+Aux Port Wi-Fi Tx on **Channel 36** at **13dBm** with an 802.11ax **MCS11 data rate** in 5GHz 20MHz BW mode

```
rtwpriv wlp5s0 mp_start  
rtwpriv wlp5s0 36 0 ab HE1MCS11 1 2000  
rtwpriv wlp5s0 mp_txpower dbm=13  
rtwpriv wlp5s0 stop
```

-
7. Main+Aux Port Wi-Fi Tx on **Channel 38** at **13dBm** with an 802.11ax **MCS11 data rate** in 5GHz 40MHz BW mode

```
rtwpriv wlp5s0 mp_start  
rtwpriv wlp5s0 38 1 ab HE1MCS11 1 2000  
rtwpriv wlp5s0 mp_txpower dbm=13  
rtwpriv wlp5s0 stop
```

-
8. Main+Aux Port Wi-Fi Tx on **Channel 42** at **13dBm** with an 802.11ax **MCS11 data rate** in 5GHz 80MHz BW mode

```
rtwpriv wlp5s0 mp_start  
rtwpriv wlp5s0 42 2 ab HE1MCS11 1 2000  
rtwpriv wlp5s0 mp_txpower dbm=13  
rtwpriv wlp5s0 stop
```

2.7. Main Port Wi-Fi single tone/CW Tx commands

1. Main Port WiFi CW Tx on **Channel 1** in 2.4GHz

```
rtwpriv wlp5s0 mp_start  
rtwpriv wlp5s0 1 0 a 11M 3 2000  
rtwpriv wlp5s0 mp_txpower dbm=19  
rtwpriv wlp5s0 stop
```

-
2. Main Port WiFi CW Tx on **Channel 36** in 5GHz

```
rtwpriv wlp5s0 mp_start
rtwpriv wlp5s0 36 0 a 54M 3 2000
rtwpriv wlp5s0 mp_txpower dbm=18
rtwpriv wlp5s0 stop
```

2.8. Aux Port Wi-Fi single tone/CW Tx commands

1. Aux Port WiFi CW Tx on [Channel 1](#) in 2.4GHz

```
rtwpriv wlp5s0 mp_start
rtwpriv wlp5s0 1 0 b 11M 3 2000
rtwpriv wlp5s0 mp_txpower dbm=19
rtwpriv wlp5s0 stop
```

2. Aux Port WiFi CW Tx on [Channel 36](#) in 5GHz

```
rtwpriv wlp5s0 mp_start
rtwpriv wlp5s0 36 0 b 54M 3 2000
rtwpriv wlp5s0 mp_txpower dbm=18
rtwpriv wlp5s0 stop
```

2.9. Main Port Wi-Fi Rx sensitivity commands

1. Main Port WiFi Rx on [Channel 1](#) in 802.11a/b/g/n/ac/ax 20MHz BW Mode

```
rtwpriv wlp5s0 mp_start
rtwpriv wlp5s0 mp_channel 1
rtwpriv wlp5s0 mp_ant_rx a
rtwpriv wlp5s0 mp_bandwidth 40M=0,shortGI=0
rtwpriv wlp5s0 mp_arx start
rtwpriv wlp5s0 mp_reset_stats
*****测试仪器发送WiFi数据包*****
rtwpriv wlp5s0 mp_arx phy
rtwpriv wlp5s0 mp_stop
```

2. Main Port WiFi Rx on [Channel 3](#) in 802.11n/ac/ax 40MHz BW Mode

```
rtwpriv wlp5s0 mp_start
rtwpriv wlp5s0 mp_channel 3
```

```
rtwpriv wlp5s0 mp_ant_rx a
rtwpriv wlp5s0 mp_bandwidth 40M=1,shortGI=0
rtwpriv wlp5s0 mp_arx start
rtwpriv wlp5s0 mp_reset_stats
*****测试仪器发送WiFi数据包*****
rtwpriv wlp5s0 mp_arx phy
rtwpriv wlp5s0 mp_stop
```

3. Main Port WiFi Rx on [Channel 42](#) in 802.11ac/ax 80MHz BW Mode

```
rtwpriv wlp5s0 mp_start
rtwpriv wlp5s0 mp_channel 42
rtwpriv wlp5s0 mp_ant_rx a
rtwpriv wlp5s0 mp_bandwidth 40M=2,shortGI=0
rtwpriv wlp5s0 mp_arx start
rtwpriv wlp5s0 mp_reset_stats
*****测试仪器发送WiFi数据包*****
rtwpriv wlp5s0 mp_arx phy
rtwpriv wlp5s0 mp_stop
```

2.10. Aux Port Wi-Fi Rx sensitivity commands

1. Aux Port WiFi Rx on [Channel 1](#) in 802.11a/b/g/n/ac/ax 20MHz BW Mode

```
rtwpriv wlp5s0 mp_start
rtwpriv wlp5s0 mp_channel 1
rtwpriv wlp5s0 mp_ant_rx b
rtwpriv wlp5s0 mp_bandwidth 40M=0,shortGI=0
rtwpriv wlp5s0 mp_arx start
rtwpriv wlp5s0 mp_reset_stats
*****测试仪器发送WiFi数据包*****
rtwpriv wlp5s0 mp_arx phy
rtwpriv wlp5s0 mp_stop
```

2. Aux Port WiFi Rx on [Channel 3](#) in 802.11n/ac/ax 40MHz BW Mode

```
rtwpriv wlp5s0 mp_start
rtwpriv wlp5s0 mp_channel 3
rtwpriv wlp5s0 mp_ant_rx b
rtwpriv wlp5s0 mp_bandwidth 40M=1,shortGI=0
rtwpriv wlp5s0 mp_arx start
```

```
rtwpriv wlp5s0 mp_reset_stats
*****测试仪器发送WiFi数据包*****
rtwpriv wlp5s0 mp_arx phy
rtwpriv wlp5s0 mp_stop
```

3. Aux Port WiFi Rx on [Channel 42](#) in 802.11ac/ax 80MHz BW Mode

```
rtwpriv wlp5s0 mp_start
rtwpriv wlp5s0 mp_channel 42
rtwpriv wlp5s0 mp_ant_rx b
rtwpriv wlp5s0 mp_bandwidth 40M=2,shortGI=0
rtwpriv wlp5s0 mp_arx start
rtwpriv wlp5s0 mp_reset_stats
*****测试仪器发送WiFi数据包*****
rtwpriv wlp5s0 mp_arx phy
rtwpriv wlp5s0 mp_stop
```

2.11. Main+Aux Ports WiFi Rx sensitivity commands

1. Main+Aux Port WiFi Rx on [Channel 1](#) in 802.11 n/ac/ax 20MHz BW Mode

```
rtwpriv wlp5s0 mp_start
rtwpriv wlp5s0 mp_channel 1
rtwpriv wlp5s0 mp_ant_rx ab
rtwpriv wlp5s0 mp_bandwidth 40M=0,shortGI=0
rtwpriv wlp5s0 mp_arx start
rtwpriv wlp5s0 mp_reset_stats
*****测试仪器发送WiFi数据包*****
rtwpriv wlp5s0 mp_arx phy
rtwpriv wlp5s0 mp_stop
```

2. Main+Aux Port WiFi Rx on [Channel 3](#) in 802.11n/ac/ax 40MHz BW Mode

```
rtwpriv wlp5s0 mp_start
rtwpriv wlp5s0 mp_channel 3
rtwpriv wlp5s0 mp_ant_rx ab
rtwpriv wlp5s0 mp_bandwidth 40M=1,shortGI=0
rtwpriv wlp5s0 mp_arx start
rtwpriv wlp5s0 mp_reset_stats
*****测试仪器发送WiFi数据包*****
rtwpriv wlp5s0 mp_arx phy
```



```
rtwpriv wlp5s0 mp_stop
```

3. Main+Aux Port WiFi Rx on [Channel 42](#) in 802.11ac/ax 80MHz BW Mode

```
rtwpriv wlp5s0 mp_start
rtwpriv wlp5s0 mp_channel 42
rtwpriv wlp5s0 mp_ant_rx ab
rtwpriv wlp5s0 mp_bandwidth 40M=2,shortGI=0
rtwpriv wlp5s0 mp_arx start
rtwpriv wlp5s0 mp_reset_stats
*****测试仪器发送WiFi数据包*****
rtwpriv wlp5s0 mp_arx phy
rtwpriv wlp5s0 mp_stop
```

3. Bluetooth RF test commands

Test environment settings:

请把 Bluetooth 测试工具 rtlbtmp 和测试 firmware 复制到机器，并修改 rtlbtmp 的运行权限。

```
cp mp_rtl8852b_fw /lib/firmware/
cp mp_rtl8852b_config /lib/firmware/
cp rtlbtmp /usr/sbin/
chmod 755 /usr/sbin/rtlbtmp
```

设置 Bluetooth 天线端口:

```
ifconfig wlp5s0 up
rtwpriv wlp5s0 mp_start
rtwpriv wlp5s0 mp_btc_path bt
rtwpriv wlp5s0 mp_ant_tx a
```

运行 Bluetooth 测试工具 rtlbtmp，并执行以下指令 enable Bluetooth RF 测试功能:

```
rtlbtmp
enable usb:/dev/rtk_btusb
```

```
root@test-PC:~# rtlbtmp
::::::::::::::::::::::::::::::::::::::::::::::::::::::::::::::::::
:::::::::::: Bluetooth MP Test Tool Starting 2022.06.20 :::::::::::
> enable usb:/dev/rtk_btusb
> enable[Success:0]
```

3.1. Bluetooth classic/EDR test mode commands

```
bt_mp_Exec 0
bt_mp_SetParam 18,1
bt_mp_Exec 40
bt_mp_Exec 38
bt_mp_Report 17
bt_mp_Exec 1
    //Start Test mode
bt_mp_Exec 0
    //Stop Test mode
```

3.2. Bluetooth classic/EDR packet Tx commands

```
bt_mp_Exec 0
bt_mp_SetParam 18,1
bt_mp_Exec 40
bt_mp_Exec 38
bt_mp_Report 17
bt_mp_SetParam 1,0x00;2,0x08;3,0x07;4,0x00;6,0xFF;7,0x00;9,0x3FFFF;11,0x000000c6967e
    //1,0x00 0x00 代表 Channel00, Channel 范围是 0~78 (十六进制表示, 0x4e 代表
Channel78, 0x27 代表 Channel39)
    //2,0x08 0x08 代表是 Packet Type 是 3DH5, 0x02 代表是 Packet Type 是 DH5, 0x05 代表
是 Packet Type 是 2DH5
    //3,0x07 0x07 代表 BT Payload 是 PRBS9, 0x00 代表 BT Payload 是 All0, 0x01 代表 BT
Payload 是 All1, 0x02 代表 BT Payload 是 0101
bt_mp_Exec 30
    //Start BT Packet Tx
bt_mp_Exec 31
    //Stop BT Packet Tx
```

3.3. Bluetooth classic/EDR continuous Tx commands

```
bt_mp_Exec 0
```

```
bt_mp_SetParam 18,1
bt_mp_Exec 40
bt_mp_Exec 38
bt_mp_Report 17
bt_mp_SetParam 1,0x00;2,0x08;3,0x07;4,0x00;6,0x7F;7,0x00;9,0x3FFFF;11,0x000000c6967e
    //1,0x00 0 代表 Channel00, Channel 范围是 0~78 (十六进制表示, 0x4e 代表 Channel78, 0x27
代表 Channel39)
    //2,0x08 0x08 代表是 Packet Type 是 3DH5, 0x02 代表是 Packet Type 是 DH5, 0x05 代表是
Packet Type 是 2DH5
    //3,0x07 0x07 代表 BT Payload 是 PRBS9, 0x00 代表 BT Payload 是 All0, 0x01 代表 BT
Payload 是 All1, 0x02 代表 BT Payload 是 0101
bt_mp_Exec 34
    //Start BT Continue Tx
bt_mp_Exec 35
    //Stop BT Continue Tx
```

3.4. Bluetooth BLE 1Mbps packet Tx commands

```
bt_mp_Exec 0
bt_mp_SetParam 18,1
bt_mp_Exec 40
bt_mp_Exec 38
bt_mp_Report 17
bt_mp_SetParam 1,0x00;2,0x09;3,0x00;7,0x00;9,0x3FFFF;11,0x000000c6967e;15,0x25;16,1
    //1,0x00 0x00 代表 Channel00, Channel 范围是 0~39 (十六进制表示, 0x13 代表 Channel19,
0x27 代表 Channel39)
    //2,0x09 代表是 Packet BLE
    //3,0x00 0x00 代表 BLE Payload 是 PRBS9, 0x04 代表 BLE Payload 是 All1, 0x05 代表 BLE
Payload 是 All0, 0x07 代表 BLE Payload 是 0101
    //16,1 1 代表 BLE 1M, 2 代表 BLE 2M
bt_mp_Exec 22
    //Start BLE Packet Tx
bt_mp_Exec 24
    //Stop BLE Packet Tx
```

3.5. Bluetooth BLE 2Mbps packet Tx commands

```
bt_mp_Exec 0
bt_mp_SetParam 18,1
bt_mp_Exec 40
bt_mp_Exec 38
bt_mp_Report 17
bt_mp_SetParam 1,0x00;2,0x09;3,0x00;7,0x00;9,0x3FFFF;11,0x000000c6967e;15,0x25;16,2
```

```
//1,0x00 0x00 代表 Channel00, Channel 范围是 0~39 (十六进制表示, 0x13 代表 Channel19,
0x27 代表 Channel39)
//2,0x09 代表是 Packet BLE
//3,0x00 0x00 代表 BLE Payload 是 PRBS9, 0x04 代表 BLE Payload 是 All1, 0x05 代表 BLE
Payload 是 All0, 0x07 代表 BLE Payload 是 0101
//16,2 1 代表 BLE 1M, 2 代表 BLE 2M
bt_mp_Exec 22
//Start BLE Packet Tx
bt_mp_Exec 24
//Stop BLE Packet Tx
```

3.6. Bluetooth BLE 1Mbps continuous Tx commands

```
bt_mp_Exec 0
bt_mp_SetParam 18,1
bt_mp_Exec 40
bt_mp_Exec 38
bt_mp_Report 17
bt_mp_SetParam 1,0x00;3,0x00;15,0xFF;16,1
//1,0x00 0x00 代表 Channel00, Channel 范围是 0~39 (十六进制表示,0x13 代表
Channel19,0x27 代表 Channel39)
//3,0x00 0x00 代表 BLE Payload 是 PRBS9, 0x04 代表 BLE Payload 是 All1, 0x05 代表 BLE
Payload 是 All0, 0x07 代表 BLE Payload 是 0101
//16,1 1 代表 BLE 1M, 2 代表 BLE 2M
bt_mp_Exec 28
//Start BLE Continuous Tx
bt_mp_Exec 29
//Stop BLE Continuous Tx
```

3.7. Bluetooth BLE 2Mbps continuous Tx commands

```
bt_mp_Exec 0
bt_mp_SetParam 18,1
bt_mp_Exec 40
bt_mp_Exec 38
bt_mp_Report 17
bt_mp_SetParam 1,0x00;3,0x00;15,0xFF;16,2
//1,0x00 0x00 代表 Channel00, Channel 范围是 0~39 (十六进制表示, 0x13 代表 Channel19,
0x27 代表 Channel39 )
//3,0x00 0x00 代表 BLE Payload 是 PRBS9, 0x04 代表 BLE Payload 是 All1, 0x05 代表 BLE
Payload 是 All0, 0x07 代表 BLE Payload 是 0101
```

```
//16,2 1 代表 BLE 1M, 2 代表 BLE 2M  
bt_mp_Exec 28  
//Start BLE Continue Tx  
bt_mp_Exec 29  
//Stop BLE Continue Tx
```

3.8. Bluetooth classic/EDR hopping mode Tx commands

```
bt_mp_Exec 0  
bt_mp_SetParam 18,1  
bt_mp_Exec 40  
bt_mp_Exec 38  
bt_mp_Report 17  
bt_mp_SetParam 2,0x08;6,0x7F;7,0x00;10,0x00;18,0,78  
//2,0x08 0x08 代表是 Packet Type 是 3DH5, 0x02 代表是 Packet Type 是 DH5, 0x05 代表是  
Packet Type 是 2DH5  
//10,0x00 代表 Enable Hopping Mode  
bt_mp_Exec 21  
//Start BT Hopping Mode  
bt_mp_Exec 0  
//Stop BT Hopping Mode
```

3.9. Bluetooth BLE hopping mode Tx commands

```
bt_mp_Exec 0  
bt_mp_SetParam 18,1  
bt_mp_Exec 40  
bt_mp_Exec 38  
bt_mp_Report 17  
bt_mp_SetParam 2,0x09;10,0x00;6,0x7F;7,0x00;18,0,39  
//2,0x09 代表是 Packet BLE  
//10,0x00 代表 Enable Hopping Mode  
bt_mp_Exec 21  
//Start BLE Hopping Mode  
bt_mp_Exec 0  
//Stop BLE Hopping Mode
```

3.10. Bluetooth/BLE single tone/CW Tx commands

```
bt_mp_Exec 0  
bt_mp_SetParam 18,1  
bt_mp_Exec 40  
bt_mp_Exec 38
```

```
bt_mp_Report 17
bt_mp_SetParam 1,0x00;2,0x08;3,0x00;4,0x00;5,0x3F;6,0xFF;7,0xFF;11,0x000000c6967e
//1,0x00 0x00 代表 Channel00, Channel 范围是 0~78 (十六进制表示,0x4e 代表 Channel78)
bt_mp_Exec 34
//Start BT Single Tone
bt_mp_Exec 35
//Stop BT Single Tone
```

3.11. Bluetooth classic/EDR packet Rx sensitivity commands

```
bt_mp_Exec 0
bt_mp_SetParam 18,1
bt_mp_Exec 40
bt_mp_SetParam 1,0x00;2,0x08;3,0x07;6,0x80;11,0x000000c6967e
//1,0x00 0 代表 Channel00, Channel 范围是 0~78 (十六进制表示, 0x4e 代表 Channel78, 0x27
代表 Channel39)
//2,0x08 0x08 代表是 Packet Type 是 3DH5, 0x02 代表是 Packet Type 是 DH5, 0x05 代表是
Packet Type 是 2DH5
//3,0x07 0x07 代表 BT Payload 是 PRBS9, 0x00 代表 BT Payload 是 All0, 0x01 代表 BT
Payload 是 All1, 0x02 代表 BT Payload 是 0101
bt_mp_Exec 32
//Start BT Packet Rx
*****测试仪器发送 Bluetooth 数据包*****
bt_mp_Report 3
//Report BT Rx number of packets
bt_mp_Exec 33
//Stop BT Packet Rx
```

```
> bt_mp_Report 3
bt_mp_Report[Success:0]
> bt_mp_Report,3,0x00,-88,0x00baf360,0x000005dc,0x0000d5a0
```

e.g. 5dc(hex) that received 1500 packets

3.12. Bluetooth BLE Packet Rx sensitivity commands

```
bt_mp_Exec 0
bt_mp_SetParam 18,1
bt_mp_Exec 40
bt_mp_SetParam 1,0x00;16,0x01;17,0x00
//1,0x00 0x00 代表 Channel00, Channel 范围是 0~39 (十六进制表示,0x13 代表
Channel19,0x27 代表 Channel39) ;
```

```
//16,0x01      0x01 代表 BLE 1M, 0x02 代表 BLE 2M  
bt_mp_Exec 23  
  //Start BLE Packet Rx  
*****测试仪器发送 BLE 数据包*****  
bt_mp_Exec 24  
  //Stop BT Packet Rx  
bt_mp_Report 11  
  //Report LE Rx number of packets
```

```
> bt_mp_Report 11  
bt_mp_Report[Success:0]  
> bt_mp_Report,11,0x00,0x000005dc
```

e.g. 5dc(hex) that received 1500 packets